



| | |
|---|---|
| Product | Lift for wall cupboard, electrically height adjustable |
| Actuator (motor) | LA31 Deskline (Linak), 1500N, IPX1 |
| Control box | CBD6 (Linak) |
| Wired remote control | HB53 (Linak), IPX1 |
| Power consumption (maximum load) | Power consumption by maximum load: 187 W Power consumption by standby: 1,5 W |
| Warranty | Pressalit makes a commitment to remedy material and manufacturing defects for a period of three years from the invoicing date. |
| Cleaning | <p>INDIVO lift for kitchenwall cupboard. The product is to be cleaned with hot water or a mild soapy cleaning agent. Do not use chlorine based, corrosive or abrasive cleaners as it may result in the surface being damaged.</p> <p>The following cleaning agents have been tested by Pressalit and may be used, as long as they are diluted according to the instructions on the container.</p> <p>DISINFECTANTS: Clinimax Difficil-S Erisan OXY+</p> <p>NON-DISINFECTANTS: Suma Star free D1 Taski 100 Taski 200</p> <p>The product must be wiped down with a soft rag wrung out in clear water immediately after cleaning, as some materials may otherwise be discolored and stained, and the surface coating may deteriorate.</p> <p>DECALCIFICATION OF ALUMINUM PARTS: Pressalit recommends that chalky deposits be removed from wall tracks and other aluminum parts using a solution of three parts 30% acetic acid to seven parts tap water. When the aluminum parts have been washed down with this solution, the parts must be wiped over with a damp cloth wrung out in clear water.</p> |





PRESSALIT®

| | |
|----------------|--|
| Product | Lift for wall cupboard, electrically height adjustable |
|----------------|--|



www.pressalit.com

Pressalit A/S
Pressalitvej 1
DK-8680 Ry
Tel.: +45 8788 8788
Fax: +45 8788 8789
E-mail: pressalit@pressalit.com

PRESSALIT®